













3270+3280 (+3292)

REVERSIBILE
RÉVERSIBLE
REVERSIBLE
UMKEHRBAR
OMKEERBAAR





ISTRUZIONI DI MONTAGGIO
NOTICES DE POSE
ASSEMBLING INSTRUCTIONS

MONTAGE ANLEITUNGEN
MONTAGE VOORSCHRIFT
INSTRUCCIONES DE MONTAJE

cesana 






art.	L
3270	64 cm
3271	74 cm
3272	84 cm
3273	94 cm
3274	114 cm
3275	124 cm
3276	134 cm
3277	144 cm
3278	154 cm



Attenzione
Siliconare solo all'esterno
Attention
Siliconer seulement a l'exterieur
Attention
Seal only outside
Attentie
Alleen aan buitenzijde afkitten
Achtung
Silikon nur auf der aussenseite
Atenciòn
Siliconar solo por el exterior

3270
+
3280
+
3292



Attenzione
Siliconare solo all'esterno
Attention
Siliconer seulement a l'exterieur
Attention
Seal only outside
Attentie
Alleen aan buitenzijde afkitten
Achtung
Silikon nur auf der aussenseite
Atenciòn
Siliconar solo por el exterior