












361x















cesana 

REVERSIBILE
REVERSIBLE
RÉVERSIBLE
UMKEHRBAR
OMKEERBAAR
REVERSIBLE

Istruzioni di montaggio
Notices de pose
Assembling instructions
Montageanleitungen
Montage voorschrift
Instrucciones de montaje

Codice articolo	Estensibilità in cm
361A	69,5 ÷ 72,0
361B	72,0 ÷ 74,5
361C	74,5 ÷ 77,0
361D	77,0 ÷ 79,5
361E	79,5 ÷ 82,0
361F	82,0 ÷ 84,5
361G	84,5 ÷ 87,0
361H	87,0 ÷ 89,5
361I	89,5 ÷ 92,0
361L	92,0 ÷ 94,5
361M	94,5 ÷ 97,0
361N	97,0 ÷ 99,5





Attenzione
 Siliconare solo all'esterno
Attention
 Siliconer seulement a l'exterieur
Attention
 Seal only outside
Attentie
 Alleen aan buitenzijde afkitten
Achtung
 Silikon nur auf der aussenseite
Atenciòn
 Siliconar solo por el exterior