













3270+3280 (+3292)

REVERSIBILE
RÉVERSIBLE
REVERSIBLE
UMKEHRBAR
OMKEERBAAR

ISTRUZIONI DI MONTAGGIO
NOTICES DE POSE
ASSEMBLING INSTRUCTIONS

MONTAGE ANLEITUNGEN
MONTAGE VOORSCHRIFT
INSTRUCCIONES DE MONTAJE





cesana 



art.	L
3273	94 cm
3274	114 cm
3275	124 cm
3276	134 cm
3277	144 cm
3278	154 cm




202 cm





Attenzione
Siliconare solo all'esterno
Attention
Siliconer seulement a l'exterieur
Attention
Seal only outside
Attentie
Alleen aan buitenzijde afkitten
Achtung
Silikon nur auf der aussenseite
Atenciòn
Siliconar solo por el exterior

3270
+
3280
+
3292



Attenzione
Siliconare solo all'esterno
Attention
Siliconer seulement a l'exterieur
Attention
Seal only outside
Attentie
Alleen aan buitenzijde afkitten
Achtung
Silikon nur auf der aussenseite
Atenciòn
Siliconar solo por el exterior